



MA4

EN

INSTALLER AND USER'S MANUAL

V3.0
REV. 07/2019

STEP 1 • Make the cable rise up at least 50mm above the fixation plate.

STEP 2 • After, descend the cable in a vertical position.

STEP 3 • To finalize, direct the cable horizontally to the motor.



Taking into account these indications, will ensure that the automatism is not damaged by humidity.

Technical Parameters

• Total cable length: **2,40m**

INSTALLATION

